

TESTING INSTRUCTION OF COM3C

- | | | |
|---|------------------------------|-----------------------------|
| BP1 and BP2 are released
* ON LED lights red and V1 and V2 are off.
* Check the continuity of lines thanks to the tester:
* 13 and 14 open
* 23 and 24 open
* 31 and 32 closed | YES <input type="checkbox"/> | NO <input type="checkbox"/> |
| Simultaneous pushed BP1 and BP2
* V1, V2, ON LEDs light.
* Check the continuity of lines thanks to the tester:
* 13 and 14 closed
* 23 and 24 closed
* 31 and 32 open | YES <input type="checkbox"/> | NO <input type="checkbox"/> |
| BP1 pushed & BP2 shifted
* ON LED lights red and V1, V2 are off.
* Check the continuity of lines thanks to the tester:
* 13 and 14 open
* 23 and 24 open
* 31 and 32 closed | YES <input type="checkbox"/> | NO <input type="checkbox"/> |
| BP1 pushed and BP2 shifted
* ON LED lights red and V1, V2 are off.
* Check the continuity of lines thanks to the tester:
* 13 and 14 open
* 23 and 24 open
* 31 and 32 closed | YES <input type="checkbox"/> | NO <input type="checkbox"/> |
| Repeat five times all steps. | YES <input type="checkbox"/> | NO <input type="checkbox"/> |

ALL PARAMETERS MUST BE WRITE «YES»

**All the sheets must be archived, they will be requested by a control body.
This sheet must be attached if the product is returned to the manufacturer.**

VERIFY Name : Date : Visa :	APPROVED Nom : Date : Visa :
---	--

INSTRUCTION DE TEST DE COM3C

- | | | |
|---|------------------------------|------------------------------|
| BP1 et BP2 sont relâchés
* LED ON allumée et LED V1, V2 éteintes.
* Vérifier la continuité des lignes avec un testeur :
* 13 et 14 ouvertes
* 23 et 24 ouvertes
* 31 et 32 fermée | OUI <input type="checkbox"/> | NON <input type="checkbox"/> |
| Appui simultané sur BP1 et BP2
* LED V1, V2, ON allumées.
* Vérifier la continuité des lignes avec un testeur :
* 13 et 14 fermées
* 23 et 24 fermées
* 31 et 32 ouverte | OUI <input type="checkbox"/> | NON <input type="checkbox"/> |
| BP1 relâché et BP2 appuyé
* LED V1 et V2 éteintes, LED ON allumée.
* Vérifier la continuité des lignes avec un testeur :
* 13 et 14 ouvertes
* 23 et 24 ouvertes
* 31 et 32 fermée | OUI <input type="checkbox"/> | NON <input type="checkbox"/> |
| BP1 appuyé et BP2 relâché
* LED V1 et V2 éteintes, LED ON allumée.
* Vérifier la continuité des lignes avec un testeur :
* 13 et 14 ouvertes
* 23 et 24 ouvertes
* 31 et 32 fermée | OUI <input type="checkbox"/> | NON <input type="checkbox"/> |
| Répéter cinq fois toutes les étapes | OUI <input type="checkbox"/> | NON <input type="checkbox"/> |

TOUTES LES ETAPES DOIVENT ETRE MARQUEES «OUI»
Toutes les fiches doivent être archivées, elles seront demandées par un organisme de
contrôle.
Cette fiche doit être jointe si le produit est retourné au fabricant.

VERIFY

Name :
Date :
Visa :

APPROVED

Name :
Date :
Visa :

